



Map Selector Instructions

Thank you for purchasing a Specialty Z ECU Map Selector. Your Selector should come pre-programmed for the number of maps that you ordered. However, if for some reason you don't have as many maps available as you ordered, then follow these instructions:

1. Hold the hour button and click the minute button over and over till you get just a dot on the screen, then release the hour button.
2. Click the hour button to go up, or the minute button to go down, to select how many maps.
3. Let the selector time out (don't touch anything else, just let it reset).

You should now have the desired number of maps. Note: if you add more maps than the chip has, the vehicle won't run and your AC accessory fan will kick on (this is a failsafe). If this happens, you need to do these steps over again and subtract the empty map slots.

You can also adjust the contrast (brightness) of the digital display. To do this, follow these instructions:

1. Hold the minute button and click the hour button. Let go of the minute button and click it one more time. You should now see a capital **C** on the screen.
2. You can only use the hour button to go up in brightness; you cannot use the minute button to go down. The minute button is essentially an "okay" or "save" button for when you're finished. If you pass the desired number, you will have to do this sequence over again to get to a lower number.
3. As mentioned above, click the minute button when you're finished.

If you have any questions, please give us a call!

Specialty Z – (818) 703-6272